

HUBODOMETERS




Part Number	Description
650-0532	300 REV/KM
650-0537	310 REV/KM
650-0539	315 REV/KM
650-0587	480 REV/MILE
650-0591	483 REV/MILE
650-0595	494 REV/MILE
650-0598	500 REV/MILE
650-0601	504 REV/MILE

Part Number	Description
650-0605	513 REV/MILE
650-0608	520 REV/MILE
650-0609	520 REV/MILE
650-0610	522 REV/MILE
650-0613	532 REV/MILE
650-0626	570 REV/MILE
650-0672	576 REV/MILE
650-0704	663 REV/MILE

Part Number	Description
600-9999	HUBODOMETER DATATRAC PRO

HUBODOMETER BRACKETS

- 1 - Angles
- 2 - Strap
- 3 - Washer
- 4 - Nut
- 5 - Rivets



Part Number	Description
610-0011	HUBO BRACKET 5-1/2" - 7-1/2" BC UNIVERSAL MOUNT

Part Number	Description
610-0028	HUBO BRACKET 3-LEG 5-1/2" BC SENTINEL & PSI HUBCAPS
610-0084	HUBO BRACKET 3-LEG 6-3/4" BC SENTINEL & PSI HUBCAPS



Part Number	Description
610-0065	HUBO BRACKET 5-1/2" BC 3-1/2" HT